



B.C. COASTAL FISHERIES  
FORESTRY GUIDELINES

# MANAGING SEDIMENT

Protect streamside areas

Remove old  
drainage structures

Keep machinery  
out of the channel

Keep roads away  
from stream

Install culverts on  
all missed drainages

Avoid unstable areas

Streamside  
not protected

Armoured bridge  
abutments

Use culverts or  
bridges on all  
drainages

Hydroseed  
bare soil

Keep ditches open

Armour culvert outflows

Bridge structures  
outside of channel

Yard away from streams

Don't pile logs in creek

End-haul road materials  
in unstable areas

Use alternative  
harvest systems

Silt-fences sediment  
ponds and armoured fords

Maintain culverts  
and ditches

Control drainage  
during road construction

Store fuel and oil  
away from streams

Retrieve sidecast

Hand-seed bare soil

THE WAY TO DO IT

THE WAY NOT TO DO IT